

**sentryum**

**S3U IO480**

**10kVA**



## Installation manual



# SUMMARY

<b>PREPARATIONS</b>	<b>4</b>
<b>INSTALLATION ENVIRONMENT</b>	<b>4</b>
<b>ELECTROMAGNETIC COMPATIBILITY</b>	<b>5</b>
<b>PRELIMINARY INFORMATION FOR INSTALLATION</b>	<b>6</b>
<b>INTERNAL BATTERIES</b>	<b>6</b>
ALLOWED BATTERY MODELS	7
BATTERY MAINTENANCE	7
<b>INTERNAL PROTECTIVE DEVICES</b>	<b>8</b>
BACKFEED PROTECTION	8
LATCH-ON-BYPASS FUNCTION	8
<b>EXTERNAL PROTECTIVE DEVICES</b>	<b>8</b>
INPUT	8
OUTPUT	9
SHORT CIRCUIT PROTECTION	9
SHORT CIRCUIT WITHSTANDING	9
RCD BREAKER	9
<b>ELECTRICAL CONNECTIONS</b>	<b>10</b>
WIRING DIAGRAMS FOR CONNECTING THE S3U IO480 TO THE ELECTRICAL SYSTEM	10
<b>INSTALLATION</b>	<b>11</b>
<b>PRELIMINARY INFORMATION FOR INSTALLATION</b>	<b>11</b>
<b>POSITIONING INFORMATION</b>	<b>12</b>
<b>UPS DETAILS</b>	<b>14</b>
<b>POWER CONNECTION INFORMATION</b>	<b>16</b>
<b>POWER CONNECTION INSTALLATION</b>	<b>17</b>
<b>CONNECTION DETAIL</b>	<b>20</b>
POWER CONNECTIONS	20
AUXILIARY CONNECTORS	21
COMMUNICATION BOARD CONNECTORS	22
<b>BATTERY INSTALLATION</b>	<b>23</b>
<b>REMOVING DOOR</b>	<b>24</b>

## GLOSSARY OF ACRONYMS

Acronym	ITEM	Description
<b>S3U IO480</b>	Sentryum UL	<i>Three phase input-output 480V UPS</i>
<b>SW</b>	Four switch version	<i>UPS model type</i>
<b>SLOT</b>	Expansion Slot	<i>Slot to accommodate the communication cards and relays expansion board</i>
<b>COM</b>	Communication Board	<i>It includes R.E.P.O., IN/OUT signals interface, USB communication port, serial port</i>
<b>PAR</b>	Parallel Board	<i>Communication interface card between UPS for parallel function</i>
<b>EXT SYNC</b>	External Sync Connector	<i>Connector for external synchronization kit</i>
<b>EXT T_BATT</b>	External Battery Temperature Probe	<i>Connector for external battery temperature kit</i>
<b>B_BOX R.E.P.O.</b>	Battery box REPO	<i>Remote power off for the battery cabinet breaker trip coil</i>
<b>FBATT</b>	Battery Fuses	<i>Internal Battery fuses</i>
<b>SWIN</b>	Mains Input Switch	<i>Mains input switch disconnecter / breaker</i>
<b>SWOUT</b>	Output Switch	<i>Output switch disconnecter</i>
<b>B+</b>	-	<i>Positive battery voltage/current/temp.</i>
<b>B-</b>	-	<i>Negative battery voltage/current/temp.</i>
<b>CB</b>	<i>Battery Charger</i>	<i>UPS internal battery charger</i>
<b>PE</b>	<i>Protective earth</i>	<i>Earth connection of the UPS</i>

## PREPARATIONS



**SAVE THIS INSTRUCTIONS:** *This manual contains important instruction to properly install the UPS unit. Read safety manual before starting UPS installation.*



**ALL THE OPERATIONS DESCRIBED IN THIS SECTION ARE TO BE PERFORMED EXCLUSIVELY BY QUALIFIED STAFF.**



**The company declines all liability for damage caused by incorrect connections or operations not described in this manual.**

## INSTALLATION ENVIRONMENT

When choosing the site in which to install the UPS and the Battery Box, the following points should be taken into consideration:

- Avoid dusty environments
- Check that the floor is level and capable of withstanding the weight of the UPS and the Battery Box
- Avoid cramped environments that could impede the normal maintenance activities
- The relative humidity should not exceed 90%, non-condensing
- This equipment is intended for use in a controlled environment, hence the temperature must be regulated in a range between 0 and 40°C



*The UPS may be operated with an ambient temperature of between 0 and 40°C. The recommended working temperature for the UPS and the batteries is between 20 and 25°C. In fact, if the battery has an average life of 5 years with a working temperature of 20°C, the life is halved if the working temperature is increased to 30°C.*

- Avoid installing the equipment in places exposed to the direct sunlight or hot air

To keep the temperature of the installation room within the range indicated above, there must be a system for eliminating the dissipated heat (the UPS kW / kcal/h / B.T.U./h dissipation values are shown in the table on the previous page). The methods that may be used are:

- *Natural ventilation*
- *Forced ventilation*, recommended if the outside temperature is less (e.g. 20°C) than the temperature at which the UPS or Battery Box is to be operated (e.g. 25°C)
- *Air-conditioning system*, recommended if the outside temperature is higher (e.g. 30°C) than the temperature at which the UPS or Battery Box is to be operated (e.g. 25°C)

ENVIRONMENTAL CONDITIONS	
Operating temperature	0 °C ÷ 40 °C
Recommended working temperature for optimum battery performance	20 °C ÷ 25 °C
Storage temperature	-25 °C ÷ +60 °C (UPS) -15 °C ÷ +40 °C (UPS with batteries)
Max relative humidity in operation	90% (without condensation)
Max installation height	1000 m a.s.l. at nominal power (-1% power for every 100 m above 1000 m) – max 4000 m

TECHNICAL DATA		
Power	10 kVA / 9 kW	
V Input	480 V +15/-20% (3PH)	
Frequency Input	50 – 60 Hz	
V Output [Δ/Y]	480/277 V (3PH + N)	
Frequency Output	50 / 60 Hz	
Power loss with no load	0.267 kW 230 kcal/hr 912 BTU/hr	
Power loss @ 100% load (1)	0.990 kW 852 kcal/hr 3380 BTU/hr	
Flow rate of fans for removing heat from installation room (2)	528 m <sup>3</sup> /hr	
Isolation protection	IP20	
Cable input	On the rear from bottom / top without additional cabinet	
Overvoltage category/Protective class	OVC II / class I	
Net weight W/O batteries		597 lb / 271 Kg
Net weight with full battery configuration		1093 lb / 496 Kg
UPS dimensions (W x D x H)	(W/O TB cover)	21.7 x 32.7 x 59 in 550 x 830 x 1500 mm
	(With TB cover)	21.7 x 40.5 x 59 in 550 x 1030 x 1500 mm
Shipping dimensions (W x D x H)	26.8 x 41.3 x 75.6 in 680 x 1050 x 1920 mm	
Audible noise	<52 dB(A)	
Colour	Pantone Black “C”	

1)  $3.97 \text{ B.T.U./h} = 1 \text{ kcal/h}$

2) To calculate the air flow rate, the following formula may be used:  $Q [\text{m}^3/\text{h}] = 3.1 \times P_{\text{diss}} [\text{Kcal/h}] / (t_a - t_e) [^\circ\text{C}]$

$P_{\text{diss}}$  is the power expressed in Kcal/h dissipated by all the devices installed in the installation environment.

$t_a$ = ambient temperature,  $t_e$ =outside temperature. To take leaks into account, the value obtained should be increased by 10%.

The table shows an example of a flow rate with  $(t_a - t_e)=5^\circ\text{C}$  and a rated resistive load ( $\text{pf}=1$ ).

(Note: This formula is applicable if  $t_a > t_e$ , only; if the UPS installation does not require an air-conditioning system).

## ELECTROMAGNETIC COMPATIBILITY

This UPS complies with Part 15 of the FCC rules (Class A). It may cause radio interference in the home environment. The user may have to adopt supplementary measures.

This product is for professional use in industrial and commercial environments. Connections to USB must be made with the cable provided. Connection to RS232 (RJ10 connector) have to be made with a shielded cable less than 3 metres (10 ft) long.

---

## PRELIMINARY INFORMATION FOR INSTALLATION

ALL OPERATIONS DESCRIBED IN THIS SECTION MUST BE PERFORMED BY QUALIFIED AND TRAINED PERSONNEL ONLY.



*Our Company assumes no liability for damages caused by incorrect connections or operations not described in this manual.*



*The following operations have to be performed with the UPS disconnected from the power mains, off and with all equipment switches open.*

*Before making the connection, open all cabinet switches and verify that the UPS is completely isolated from power sources: battery and AC power line. In particular, check that:*

- the UPS input line is completely disconnected*
- the UPS bypass line is completely disconnected*
- the external UPS battery line switch/fuses are open*
- all UPS switches are in the open position*
- check with a multimeter that there are no dangerous voltages*



*The first connection to be made is the protective conductor (earth wire), this must be connected to the bar marked as PE with a circled earth symbol.*

*The UPS must operate while connected to the earthing system.*



*The input Neutral must always be connected.*



**ATTENTION:** *After the installation operation is complete, refit the cabinet protection panels using the appropriate screws.*

---

## INTERNAL BATTERIES



**CAUTION:** If the UPS has INTERNAL BATTERIES, follow all the PRECAUTIONS AND SAFETY RULES listed below.

- The UPS has HAZARDOUS electrical voltages inside, even when the input and/or battery switches are off. The inside of the UPS is protected by safety panels which should not be removed by untrained personnel. All installation and maintenance or operations involving access inside the UPS require the use of tools and may ONLY be performed by trained personnel.
- The UPS contains an internal source of energy: batteries. All terminals and sockets may be live even without connecting the UPS to the mains.
- The total battery voltage is potentially dangerous: it may generate an electric shock. The battery compartment is protected by safety panels which should not be removed by untrained personnel. All installation and maintenance of the batteries involve access inside the UPS and require the use of tools: such operations may ONLY be performed by trained personnel.
- Replaced batteries must be considered TOXIC WASTE and treated accordingly. Do not dispose of batteries in a fire: they may explode. Do not attempt to open the batteries: they are maintenance-free. In addition, the electrolyte is harmful to the skin and eyes and can be toxic.
- Do not turn on the UPS if it is leaking fluid or if you see a residual white powder.
- Do not allow water, liquids in general and/or other foreign objects to get inside the UPS.
- Do not open the battery fuse holder while the UPS is powering the load in battery operation mode. The interruption of the battery DC may cause an electrical arc resulting in broken equipment and/or fire. In addition, if there is no mains power, the energy to power the load is provided by the batteries, therefore opening the battery caps would lead to the shutdown of the load.
- Follow these recommendations when working on the batteries:
  - Remove wristwatches, rings and other metal objects
  - Use tools with insulated handles
  - Wear rubber shoes and gloves
  - Do not lay tools or metal objects on top of the batteries
  - Disconnect the charging source before connecting or disconnecting the battery connectors.

## ALLOWED BATTERY MODELS



Risk of explosion if batteries are replaced by an incorrect type.

Refer to the following table to identify the correct quantities and models:

Replace only with the same type and number of batteries or battery packs.

Battery Type	12V Valve regulated sealed lead-acid rechargeable
Maximum number of batteries	20+20+20+20
Total rated battery voltage	240 VDC

Manufacturer	Type	Computer room installation permitted
Hitachi Chemical Energy Technology Co Ltd (MH14533)	UPS 12460	N
	UPS 12460 FR	Y
	HRL 1234W	N
	HRL 1234W FR	Y
	HRL 1234W F2	N
	HRL 1234W FRF2	Y
	HR 1234W F2	N
	HR 1234W FRF2	Y
	UPS 12360 7 F2	N
	UPS 12360 7 F2FR	Y
Fabit Enertech Co Ltd (MH27960) Note: trademark "FIAMM"	12FGH36	N
GS Yuasa International Ltd (MH12970)	NPW45-12	N
	NPW45-12 FR	Y
Taiwan Yuasa Battery Co Ltd (MH28947)	NPW45-12	N
	NPW45-12FR	Y
Yuasa Battery (Guangdong) Co Ltd (MH29616)	NPW45-12	N
	NPW45-12FR	Y



**ATTENTION:** If the installed batteries are less than V-2 flame class, the Ups is considered *not for use in a computer room* as defined in the Standard for the Protection of Electronic Computer/Data Processing Equipment, ANSI/NFPA 75. Please refer to the table above.

For correct interconnection of the batteries, refer to the wiring diagrams available to service personnel only or to the battery kit installation manual.

## BATTERY MAINTENANCE



### **WARNING: HAZARDOUS VOLTAGE INSIDE!**

**Never open the battery compartment for any reason. If any anomaly is noted, please contact the service department.**



In order to preserve a high level of efficiency and a good lifespan, the batteries must be periodically charged using the UPS itself.

Batteries are subject to self-discharge. If the internal batteries or the battery boxes are stocked and not immediately installed, a full charge must be performed.

In order to re-charge the batteries, it is required to connect the battery box or the batteries internal to the UPS unit for at least 24hrs in "NORMAL MODE".

If a long battery stocking period is planned, please contact the service department.



---

## INTERNAL PROTECTIVE DEVICES

The table below shows the sizes of the switch, breaker and battery fuses: these devices are accessible from the UPS front. There are also indications about the internal fuses (not accessible) protecting the input and output lines, the bypass and the DC circuit.

Fuses must be replaced with ones of the same size and type, as indicated in the table below.

UPS (kVA)	UPS Switch disconnectors, breakers and internal protective devices			
10	Disconnect switches	Breakers		Fuses (front access)
	Output switch (SWOUT)	Input breaker (SWIN)		Main battery fuses*
	80A (3P)	20A, K curve		FWH-125
	Internal fuses (not accessible from the front)			
	Rectifier input fuses*	Fast DC fuses*	Output fuse*	Bypass fuse*
	100 LET	63 FE	35 LET	160LET

\*All fuses mentioned in this table are manufactured by COOPER BUSSMANN

### BACKFEED PROTECTION

The UPS is electronically protected against backfeed. This protection acts by means of a sensing circuit which turns off the inverter if a fault on the static switch is detected. In this condition, to avoid interrupting the load supply, the UPS switches to bypass line.

An optional dry contact is provided for the driving of a disconnecting device to be installed upstream to the UPS.

A dry contact can be set to drive a disconnecting device to be installed upstream the UPS, in this case when a backfeed fault occurs, the system opens the external disconnecting device avoiding the stop of the inverter.

See user manual for function configuration.

### LATCH-ON-BYPASS FUNCTION



*The UPS has an internal device (redundant bypass power supply) which activates the bypass automatically when a failure occurs on the machine; thus keeping the load powered without any internal protection and without any limitation to the power supplied to the load.*

*Under these emergency conditions, any disturbance present at the input line will affect the load.*

---

## EXTERNAL PROTECTIVE DEVICES

### EXTERNAL OVERCURRENT PROTECTIONS

#### INPUT

To reduce the risk of fire, AC input terminals of each UPS should be connected to a branch circuit breaker with maximum overcurrent protection in accordance with the National Electric Code, ANSI/NFPA 70.

The sizing must be based on the cables used for the wiring of UPS input and taking into account selectivity with the integrated overcurrent devices at the UPS input (see table above).

## OUTPUT

To avoid potential safety hazards and unwanted power outages the system must be designed with proper selectivity. This will assure that only the overcurrent protection device for a faulted circuit will open.

To limit a power outage to the faulted circuit, select the UPS output protection devices according to the table below:

Output protections (recommended values for selectivity)	
Normal fuses (GI)	$I_n (\text{Nominal current})/4$
Breakers (C curve)	$I_n (\text{Nominal current})/4$
Ultra-fast fuses (GF)	$I_n (\text{Nominal current})/3$

## SHORT CIRCUIT PROTECTION

If a failure at the output occurs, the UPS protects itself by limiting the value and duration of the current output (short-circuit current). These values also depend on the operating status of the UPS at the time of the failure; there are two different cases:

- UPS in NORMAL OPERATION with bypass: the load is instantly switched to the bypass line, the input line is connected to the output (blocked after  $t > 500\text{ms}$ ).
- UPS in NORMAL OPERATION without bypass: the UPS protects itself supplying 2.5 times the nominal current to the output for the first 200ms, which is then reduced to 1.5 times nominal for 300 ms. After this time (500 ms) it switches off.
- UPS in BATTERY OPERATION: the UPS protects itself supplying 2.5 times the nominal current to the output for the first 200ms, which is then reduced to 1.5 times nominal for 300 ms. After this time (500 ms) it switches off.

## SHORT CIRCUIT WITHSTANDING

This equipment is rated for use on a circuit capable of delivering no more than 5kA, at 480V maximum.

## RCD BREAKER



**WARNING:** risk of electric shock from high leakage current.  
The earth leakage current of this UPS may exceed 3.5 mA.  
A proper earth connection must be provided.

Basing on the electrical system adopted, a Residual Current Device may be requested by the local regulations.

Transient and steady-state earth leakage currents, which may occur when starting the equipment, and the additional leakage current of the load should be taken into account when selecting instantaneous RCD or GFI devices.

During normal operation, when the mains supply is present, a RCD breaker at the input of the UPS will activate if a fault occurs at the output side, since the output circuit is not isolated from the input.

In any case, other RCD breakers may still be installed at the output, preferably in coordination with those present at the input.


Residual current devices must be selected sensitive to DC unidirectional pulses and insensitive to transient current pulses.

## ELECTRICAL CONNECTIONS



*The UPS must be connected to a power supply line made up of 3 phases + PE (protective earth) and must be earthed in accordance with the local electrical code of practice. The phase sequence must be respected. If a neutral wire is connected to the input, this connection is not bound to the output neutral and the output neutral is not connected to earth.*

### WIRING DIAGRAMS FOR CONNECTING THE S3U IO480 TO THE ELECTRICAL SYSTEM




Input transformer vectorial group is: *Dzn0*

Output transformer vectorial group is: *Yan0*

\* LVS: low voltage source (480V)

# INSTALLATION

READ "SAFETY MANUAL" BEFORE STARTING THE UPS INSTALLATION



## PRELIMINARY INFORMATION FOR INSTALLATION



**ALL OPERATIONS DESCRIBED IN THIS SECTION MUST BE PERFORMED BY QUALIFIED AND TRAINED PERSONNEL ONLY.**




*Our Company assumes no liability for damages caused by incorrect connections or operations not contained in this manual.*

*The following operations have to be performed with the UPS disconnected from the power mains, and with all equipment switches open.*


*Before making the connection, open all cabinet switches and verify that the UPS is completely isolated from power sources: battery and AC power line. In particular, check that:*

- the UPS input line is completely disconnected*
- the UPS bypass line is completely disconnected*
- the external UPS battery line switch/fuses are open*
- all UPS switches are in the open position*
- all the battery drawers connectors are unplugged*
- the battery cabinet protective device is in the open position*
- check with a multimeter that there are no dangerous voltages on ac and dc terminal blocks*


**POSITIONING INFORMATION**




FRONT VIEW




REAR VIEW



TOP VIEW



BOTTOM VIEW



SIDE VIEW

## UPS CABINET POSITIONING

When positioning, take into account that:

- the wheels are to be used for final positioning only. Suitable moving equipment must be used to transport the UPS near to the final position.
- plastic parts and the door are not able to act as pushing points or handles.
- for user operation and maintenance, is needed to ensure enough free space in front of the UPS ( $\approx 1.5$  m).
- no objects should rest on the upper part of the UPS.



### WARNING!

The UPS must be positioned on a level floor.

Ensure that the floor can support the total weight of the system. Refer to the TECHNICAL DATA table.


**After positioning, lower the four feet at the floor, using an appropriate spanner.**

**Ensure that the total weight of the cabinet is distributed on feet only (the casters must be lifted from floor).**


**Ensure that the UPS is level.**

It is possible to reuse the brackets for pallet fastening to anchor the UPS to the floor.

## UPS DETAILS




**FRONT**



**REAR**



**Cold start button:** This button allows the user to turn the UPS on from battery, even without the mains present. Refer to User Manual for further information.



**Communication slots:** The UPS is endowed with two communication slots to host optional boards. Slots are not generally interchangeable.

### **SLOT 1 - Communication Slot**


Slot to accommodate the communication cards (e.g. Netman 204).

### **SLOT 2 - Relay Slot**

Slot to accommodate an additional communication board (default configuration), or relay expansion boards (e.g. Multicom 384 and Multicom 392, to be set by configuration software).


Please refer to the optional board kit user manual for further information.

R.E.P.O.




**R.E.P.O. :** Emergency Power Off contact.

**C**




**Programmable auxiliary contacts:** Programmable input and output contacts.

**D**




**Communication ports:** The UPS is provided with two serial ports (USB and RS232) for computer connection.

**E**




**Parallel board (optional):** The optional parallel kit will enable the connection of up to six units in parallel.

**F**




**Touch screen display and led indicator:** Through the 5" touch panel display the user can monitor the system parameter and configure the UPS. The Riello logo backlight color indicates the system status. Refer to User Manual for further information.

**G**



**Power module handles:** In case of frontal service the UPS power module can be removed. Pull out the module from these handles.

**H**



**Switch disconnectors handles:** input, output switches. The closed position is vertical.

**I**

**Battery fuses cover:** service personnel can access the battery fuse by removing this hatch.


**WARNING:** the fuses are always energized by the battery. Before opening the fuse cover, disconnect all the battery drawers and open the battery box breaker (if present).

**J**

**Battery drawers cover:** Service personnel can access battery drawers by opening this cover.

**WARNING:** Be sure to disconnect all drawer connectors before performing any maintenance activity on the UPS

**K**



**External signals cover:** remove this cover to access the external signal connectors.

- EXT T-BATT
- EXT SYNCH
- BATTERY BOX REPO

See "auxiliary connectors section" below for further informations

**L**

**Terminal blocks cover:** remove this cover to access the terminal blocks for UPS wiring.

**M**

**Cable output:** This aluminum panel can be drilled for cable output. To maintain the IP20 protection degree, suitable cable glands must be used.



## POWER CONNECTION INFORMATION

Wiring information:

For power cable connection, use Phoenix Contact "Al" type copper ferrules (or equivalent) of proper diameter, crimp with suitable hexagonal shape crimping tool.

Use torque force indicated in the following tables when connecting AC and DC wiring terminals.

INPUT AC Line Connection 3PH + PE (Single / Dual Mains)									
UPS size	Max Power [kW-kVA]	Max Current [A]	Terminal A, B, C, N		PE		Wire A, B, C, N, PE		
			Maximum cross section	Tight. torque [in-lb]	Maximum cross section	Tight. torque [in-lb]	Type	Cross sectional area A, B, C, N**	Cross sectional area PE**
10	9 - 10	18	AWG 2/0	94	AWG 2/0	110	75°C copper wire	AWG 10*	AWG 10
							90°C copper wire	AWG 12*	AWG 10

OUTPUT AC Line Connection 3PH + N + PE									
UPS size	Max Power [kW-kVA]	Nominal current [A]	Terminal A, B, C, N		PE		Wire A, B, C, N, PE		
			Maximum cross section	Tight. torque [in-lb]	Maximum cross section	Tight. torque [in-lb]	Type	Cross sectional area A, B, C, N	Cross sectional area PE
10	9 - 10	12	AWG 2/0	94	AWG 2/0	110	75°C copper wire	AWG 10*	AWG 10
							90°C copper wire	AWG 12*	AWG 10


Input Battery DC Line Connection BATT+, BATT-, PE (Nominal voltage 240V)									
UPS size	Max Power [kW-kVA]	Rated Current [A]		Terminal BATT +, BATT -		PE		Wire BATT +, BATT -, PE **	
		@nominal battery voltage	@end of discharge voltage	Maximum cross section	Tight. torque [in-lb]	Maximum cross section	Tight. torque [in-lb]	Type	Cross sectional area +, -
10	9 - 10	40	50	AWG 2/0	94	AWG 2/0	110	75°C copper wire	AWG 4*
								90°C copper wire	AWG 6*

(\*) The suggested cross sections are calculated for an ambient temperature of 40°C maximum. If different cables are used, or installed at a higher ambient temperature, the cable size needs to be reviewed according to the National Electric Code (Table 310.16).

(\*\*) The maximum length of the cables for connecting the Battery Box (optional) is 10 metres (33 ft).



## POWER CONNECTION INSTALLATION

To install the UPS to the power mains, follow the indications below:




Remove the terminal block cover aluminum panel.

Make on the panel the appropriate holes to pass the input/output power cables according to plant needs. If needed, use suitable cable glands to achieve the required degree of protection.




Remove the upper cover to access the terminal blocks.




Put the aluminum plate in place after inserting the power cables through it.  
Connect the power cables to terminal blocks.

ATTENTION: connect always the PE wire first.

Close the top cover with the previously removed screws.





If top cable entry is required by the installation, the rear terminal cover can be rotated by 180 degrees to enable the wiring to exit upward.


## CONNECTION DETAIL



*The first wire to be connected is the protective earth wire, which is to be inserted in the terminal marked PE with a circled earth symbol. During operation the UPS must be connected to the earthing system.*

Connect the input and output cables to the terminal blocks as indicated in the figure below:

### POWER CONNECTIONS



**ALWAYS CONNECT THE PROTECTIVE EARTH WIRE (PE) FIRST.**

**Note:** This UPS does not need an input neutral connection (delta connection), nevertheless, if needed, the dedicated terminal block can be used to fit an input neutral cable, if present. This cable will be not connected to the output neutral unless a proper bridge is installed. Also the output terminal blocks are provided with a neutral connection since the UPS output has a Wye (Star) connection.




*The neutral connection on the secondary circuit is **NOT** connected to earth. It must be bound to earth according with the neutral arrangements on the site.*

**Note:** the connections to the BATTERY terminal blocks are only to be made if the (optional) Battery Box is present.



**WARNING:** Before connecting the battery box, remove all the connectors from the battery drawers.

## AUXILIARY CONNECTORS



### EXT T\_BATT External battery box temperature

- Through this input the UPS is able to read the temperature of the external batteries and compensate the floating charge level.

For more information please refer to the “BATTERY BOX INSTALLATION” section of this manual.

WARNING: This input is not isolated.

### EXTERNAL SYNC External synchronization

- Through this input it is possible to synchronize the output with an external source having the same frequency of the inverter output.

For more information please refer to the “OPTION” section of this manual.

### B\_BOX REPO Battery box breaker remote trip

- Connect the battery box REPO wires to the battery box to make the battery breaker trip when the UPS REPO is pressed to disconnect the battery circuit from UPS.

This feature is required by National Electrical Code (Article 645.11) and it is mandatory for computer room installations.

## COMMUNICATION BOARD CONNECTORS


**R.E.P.O.:** This isolated input is used to turn off the UPS remotely in case of emergency.

The UPS is supplied from the factory with the "Remote Emergency Power Off" (R.E.P.O.) terminals short-circuited. If it is to be installed, remove the short-circuit and connect to the normally closed contact of the stop device using a cable that provides a double isolation connection.


In case of emergency, by activating the stop device, the R.E.P.O. control is opened and the UPS shut-down (see USER MANUAL), and powers off the load completely.

The R.E.P.O. circuit is self-powered with SELV type circuits. No external power supply voltage is therefore required. When it is closed (normal condition), a maximum current of 15mA is present.


R.E.P.O.



**IN/OUT Programmable in/out ports:** These contacts can be programmed by the user with the configuration software for additional interfacing.



In case of external maintenance bypass or battery box installation, the relative switch auxiliary contacts must be connected to these inputs.




The output dry contacts are rated 1A @ 24Vdc or 1A @ 30Vac

**Communication ports:** Use these ports to connect the UPS to a personal computer for remote monitoring, service configuration or firmware update.

These two ports cannot be used together. The USB port is to be used in alternative to the RS232 serial interface.

USB port function is guaranteed only with cable length within 1,5m (5 ft). In case of longer wire, RS232 serial interface is recommended.

USB SERIAL



**WARNING:** These connectors are not intended for connection to the telephone network.

# BATTERY INSTALLATION

The UPS can be provided with dedicated battery drawers to allow an easy installation or replacement of the batteries.

**WARNING:** for your safety and that of the product, the information below should be carefully followed.

The nominal battery voltage of this UPS is 240V which corresponds to twenty 12V batteries in series.  
Since each drawer contains ten batteries in series, the drawers must be installed in multiple-of-two quantity.  
Look at the table below for information about the minimum number of batteries:


Minimum battery capacity	
UPS model	S3U IO480
Minimum capacity: (number of battery drawers / total n° of batteries)	9Ah (1/20)



**WARNING:** The installation of a battery capacity smaller than the recommended, could lead to a load loss when UPS switches to battery mode due to the intervention of the battery drawers overcurrent protection.




**ATTENTION:** the battery drawers are very heavy. Be very careful when installing them.  
Battery drawers have to be installed exclusively by qualified staff.  
Before installing the batteries, put the UPS in maintenance bypass mode (see user manual) and shut down the UPS.




1. The battery packs are located behind the UPS front-bottom panel.  
To install/replace the batteries, remove the cover panel and the drawers retaining bracket.

2. Remove the exhausted batteries, if present, by removing all connectors and pulling the drawers outwards.  
Insert all the new battery drawers and insert the connectors back.

**WARNING:** the new battery pack must have the same number and type of batteries as the one it is replacing.








3. Once the batteries are installed in the UPS, put the retaining bracket and the cover panel back in place.

Once the new battery drawers have been secured and panel is closed, turn on the UPS again and open the manual bypass switch following the instruction in the user manual.

## REMOVING DOOR









[www.riello-ups.com](http://www.riello-ups.com)

RPS SpA – *Riello Power Solutions*  
Viale Europa, 7  
37045 Legnago (VR)  
Italy

0MLS3UK10R1EN1B